BRC4BDY / BRC4GBL / BRC4IV 90cm Twin cavity rustic style range cooker

Instruction manual



Baumatic®

User Manual for your Baumatic

BRC4BDY / BRC4GBL / BRC4IV
90cm Twin cavity rustic style range cooker

Baumatic®

NOTE: ***This User Instruction Manual contains important information, including safety & installation points, which will enable you to get the most out of your appliance. Please keep it in a safe place so that it is easily available for future reference; for you or any person not familiar with the operation of the appliance.***

DD 24/04/09

Contents

Environmental note	4
Important safety information	5 – 9
Specifications	9 – 11
Control panel	11
Thermostat control knob (main oven)	11
Oven function selector knob (main oven)	11
Oven function and thermostat control knob (secondary oven)	11
Analogue clock with cut off timer	11
Setting the analogue clock and using the cut off timer	12 - 13
Setting the time	12
Selecting manual operation mode	12
Setting the cut off timer	12 - 13
Selecting a cooking function and temperature	13 - 20
Selecting manual operation mode	13
Before first use	13 - 14
Selecting a main oven function	14 – 15
Thermostat control knob (main oven)	15
Selecting an oven function and temperature (secondary oven)	16
Oven operating light	16
The cooling fan	17
Fitting the grill deflector (secondary oven)	17
Using and assembling the rotisserie	18
Cooking guidelines	19
Warnings	20
Using the hob top	21 - 22
Automatic electric ignition	21
Energy saving tips	22
Cleaning and maintenance	22 - 25
Cleaning the hob burners	23 - 24
Maintaining cast iron pan stands	24
Replacing the oven bulb	24
Removing the oven door for cleaning	25
Installation	26 - 35
Positioning	26 - 28
Gas connection	28
Ventilation requirements	28 – 29
Gas Safety (Installation and Use) Regulations	29
Gas connection	30
Gas adjustment (Conversion to LPG)	31 - 32
Minimum flow adjustment for hob gas taps	32
Fitting a stability chain	33
Electrical connection	34
Connecting the mains supply cable	34 – 35
Replacing the mains supply cable	35
My appliance isn't working correctly	36 – 37
Contact details	38

Environmental note

This appliance is marked according to the European directive 2002/96/EC on Waste electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol **on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.**

Disposal must be carried out in accordance with local environmental regulations for waste disposal.
For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

- The packaging materials that Baumatic uses are environmentally friendly and can be recycled.
- Please discard all packaging material with due regard for the environment.

Important safety information

Your safety is of the utmost importance to Baumatic. Please make sure that you read this instruction booklet **before** attempting to install or use the appliance. If you are unsure of any of the information contained in this booklet, please contact the Baumatic Advice Line.

General Information

- This appliance is designed for domestic household use and for the cooking of domestic foodstuffs.

- **IMPORTANT:** The adjacent furniture and all materials used in the installation **must** be able to withstand a minimum temperature of 85°C above the ambient temperature of the room it is located in, whilst in use.

- Certain types of vinyl or laminate kitchen furniture are particularly prone to heat damage or discolouration at temperatures below the guidelines given above.

- Any damage caused by the appliance being installed in contravention of this temperature limit **will be the liability of the owner.**

- **IMPORTANT:** Baumatic Ltd. **DO NOT** recommend that this appliance is installed on any type of marine vessel.

- The use of this appliance for any other purpose or in any other environment without the express agreement of Baumatic Ltd. will invalidate any warranty or liability claim.

- Your new appliance is guaranteed against electrical or mechanical defects, subject to certain exclusions that are noted in Baumatic's Conditions Of Guarantee. The foregoing does not affect your statutory rights.

- **Repairs may only be carried out by Baumatic service engineers or their authorised service agent.**

Warning and safety instructions

- This appliance complies with all current European safety legislation. Baumatic do wish to emphasise that this compliance does not remove the fact that the appliance surfaces **will become hot during use and retain heat after operation.**

Child Safety

- Baumatic strongly recommend that babies and young children are prevented from being near to the appliance and not allowed to touch the appliance **at any time.** During and after use, all surfaces will become hot.

- If it is necessary for younger family members to be in the kitchen, please ensure that they are kept under close supervision at all times.

General Safety

- Make sure that you understand the controls before using the appliance.

- Check that all of the controls on the appliance are turned off after use.

- Always stand back when opening the oven door, this will allow heat to disperse.

- Take care when removing items from the oven, as the contents may be hot.

- Always keep the oven doors closed when the oven is not in use.

- Always follow the basic principles of food handling and hygiene, this will prevent the possibility of bacterial growth.

- Always keep ventilation slots clear of obstructions.

- Keep fingers away from the hinge areas when closing the door, otherwise you may trap them.

- Oven gloves should be used when placing food in the oven cavity and when removing it. Care should be taken to avoid direct contact with any of the elements in the appliance.

- **DO NOT LEAVE THE APPLIANCE UNATTENDED WHILST IN USE.**

- **Do not** place heavy objects on the oven door or lean on the oven door when it is open, as this can cause damage to the oven door hinges. Nobody should be allowed to sit or stand on any part of the cooker.

- **Do not** store chemicals, food stuffs, pressurised containers in or on the cooker or in the cabinets immediately above or near the hob burners.

- **Do not** heat up unopened food containers, as pressure can build up which may cause the container to burst.

- **Do not** place flammable or plastic items on or near the hob burners, these types of materials should also not be placed in the oven or the compartment below the oven.

- **Do not** leave heated oil or fat unattended, as this is a fire risk. You should not fill a deep fat frying pan more than one third full of fat or oil, you should also not use a lid.

- **Do not** allow fat or oil to build up in the oven trays, grill pan or oven base.

- **Do not** place pans or baking trays directly on the base of the oven cavity, or line it with aluminium foil.

- **Do not** grill food containing fat without using the grill trivet. The grill trivet should never be covered with aluminium foil.

- **Do not** place hot enamel parts in water, leave them to cool first.

- **Do not** allow vinegar, coffee, milk, saltwater, lemon, tomato juice or any liquid with high sugar content to remain in contact with the enamel parts of the appliance. Spillages should be wiped up immediately.

- **Do not** allow electrical fittings or cables to come into contact with areas on the appliance that get hot.

- **Do not** use the appliance to heat the room it is located in or to dry clothing. No clothing should be placed over or near to the hob burners or oven door.

- **Do not** install the appliance next to curtains or soft furnishings.

- **Do not** attempt to lift or move cooking appliances by using the oven door or handle, as this may cause damage to the appliance or result in injury to the person lifting the appliance.

- **Do not** store chemicals, food stuffs, pressurised containers in or on the cooker or in cabinets immediately above or next to the cooker.

Cleaning

- Cleaning of the oven should be carried out on a regular basis.

- Great care should be taken whilst using this appliance and when following the cleaning procedure.

- **IMPORTANT:** The appliance must be disconnected from the mains before following the cleaning procedure.

Installation

This appliance must be correctly installed by a suitably qualified person, strictly in accordance with the manufacturer's instructions. Please see the specific section of this booklet that refers to installation.

- **Baumatic Ltd. declines any responsibility for injury or damage, to person or property, as a result of improper use or installation of this appliance.**

- Heat, steam and moisture will be created during use of the appliance, take care to avoid injury and ensure that the room is adequately ventilated. If the appliance is going to be used for prolonged periods of time, then additional ventilation may be required.

- Please consult with your qualified installer if you are in any doubt about the amount of ventilation that you will require.

Declaration of conformity

This appliance complies with the following European Directives:

-73/23/EEC regarding "low voltage"
-89/336/EEC regarding "electromagnetic disturbances"
-90/396/EEC regarding "gas appliances"
-89/109/EEC regarding "materials in contact with food".

- The above directives comply with 93/68/EEC regarding CE marking.

- The manufacturer declares that the oven is built using certified materials and requires the appliance to be installed in accordance with the standards currently in force. This appliance must be used by a trained person for domestic purposes only.

Specifications

Product dimensions:



Height: 870 - 920 mm
Width: 898 mm
Depth: 600 mm

Product specifications:

- **5 burner gas hob:**
- 1 x 3.60 kW triple crown (wok) burner
- 1 x 3.00 kW rapid burner
- 2 x 1.75 kW semi-rapid burners
- 1 x 1.00 kW auxiliary burner
- Heavy duty cast iron pan stands
- Flame failure safety device on each burner
- Automatic ignition

- **8 function multifunction main oven**
- Main oven capacity: 61 litres

- **5 function static secondary oven**
- Secondary oven capacity: 35 litres

- Oven energy efficiency class: B
- Storage compartment capacity: 35 litres

- Analogue clock with cut off timer
- Cooling fan
- Thermostatically controlled grill
- Double glazed removable doors
- Adjustable feet
- Rotisserie (secondary oven)

Standard accessories:

- Wok stand
- Removable side racks
- 2 x Safety shelves
- 2 x Enamelled baking trays
- Trivet
- LPG conversion jets

Optional extras:

- BPS2 Pizza stone
- BTGRID Double-sided griddle plate

Electrical details

Rated Voltage:	230 Vac 50 Hz
Supply Connection:	20 A (double pole switched fused outlet with 3mm contact gap)
Max Rated Inputs:	3.57 kW
Mains Supply Lead:	3 core x 2.5 mm^2 (not supplied)
Oven Light Bulb:	E14 25 W/300°C screw type pigmy

Gas details

Gas Connection Type:	1/2” BSP
Gas Type (Natural Gas):	20 mbar
Gas Type (LPG):	See table on page 31 for this information.

For future reference please record the following information which can be found on the rating plate and the date of purchase which can be found on your sales invoice. The rating plate for your oven can be located by opening the door of the storage compartment.

Model Number ……..

Serial Number ……..

Date of Purchase ……..

Control Panel

Thermostat control knob (main oven)



- Use this control knob to control the temperature in the oven.

Oven function selector knob (main oven)



- Use this control knob to select the oven function and switch on the oven light in the main oven.

Oven function and thermostat control knob (secondary oven)



- Use this control knob to select the oven function and switch on the oven light in the secondary oven.

Analogue clock with cut off timer



- Use the clock to set the time, set the appliance to manual operation mode and use the cut off timer.

Setting the analogue clock and using the cut off timer

Setting the time



- Press the control knob in and turn it clockwise, until the correct time of day is set on the clock face.
- Release the control knob.

Selecting manual operation mode

- **IMPORTANT:** You must set your appliance to run in manual operation mode, before you can use your oven.
- Turn the analogue clock control knob clockwise, the symbol under the number 12 will change from the symbol to the symbol.
- Your appliance is now set in manual operation mode.

Setting the cut off timer (main oven only)

- Use the thermostat control knob to set the temperature that you require.
- Use the oven function selector knob (main oven) to select the mode of cooking that you require.
- Turn the analogue clock control knob clockwise, after the symbol, you will see a series of numbers, ranging from 90 – 10 appearing on the display.
- Each number represents how many minutes the cut off timer will countdown for. You should select the number of minutes that you wish the timer to countdown for.
- The timer will countdown until it reaches zero, at this stage a bell will sound and the oven function that you have selected will switch off.

- To cancel the audible signal, turn the analogue clock control knob clockwise to the symbol.

- Before you can use your appliance in manual operation again, you must turn the analogue clock control knob clockwise to the symbol again.

- **Important:** If you do not turn the thermostat control knob and oven function selector knob to 0. Then the appliance will continue to operate as soon as you turn the analogue clock control knob clockwise to the symbol.

Selecting a cooking function and temperature

Selecting manual operation mode

- **IMPORTANT:** You must set your appliance to run in manual operation mode, before you can use the main oven. See the previous page for details on how to set the appliance into manual operation mode.

Before first use

- To remove any residue from the oven that may have been left from the manufacturing process, you should select either the fan or conventional oven function and turn the thermostat dial to its maximum temperature setting. For the secondary oven you should select the conventional oven function and select its maximum temperature setting.

- It is perfectly normal for a smell to be produced during this process.

- You should make sure that any windows in the room are left open during this process.

- It is advisable for you not to remain in the room whilst the burning off process is taking place.

- You should leave each oven on maximum setting for 30 – 40 minutes.

- **IMPORTANT: You should not burn off both ovens simultaneously.**

- After both cavities have cooled, they should then be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.

- Outer parts of the oven should be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.

- We would recommend that an appropriate stainless steel cleaner and polish is regularly used on the stainless steel surfaces of this appliance.

Selecting a main oven function



The main oven function selector knob should be turned clockwise and used to select the particular mode of cooking that you require. The appliance will utilise different elements within the oven cavity, depending on the oven function that you select. When a function is selected, the power indicator light will come on.

There are eight cooking functions available on your appliance:

OVEN LIGHT: Separate light control which allows the light to be switched on, even when the oven is not heating.

DEFROST MODE: The fan runs without heat to reduce the defrosting time of frozen foods. The time required to defrost the food will depend on the room temperature, the quantity and type of food. Always check food packaging for the defrosting instructions.

CONVENTIONAL OVEN (top and lower element): This method of cooking provides traditional cooking, with heat from the top and lower elements. This function is suitable for roasting and baking on one shelf only.

FAN OVEN: This method of cooking uses the circular element while the heat is distributed by the fan. This results in a faster and more economical cooking process. The fan oven allows food to be cooked simultaneously on different shelves, preventing the transmission of smells and tastes from one dish onto another.

HALF GRILL: This method of cooking utilises the inner part only of the top element, which directs heat downwards onto the food. This function is suitable for grilling small portions of bacon, toast and meat etc. The thermostat control knob must be turned to its maximum setting.

FULL GRILL: This method of cooking utilises the inner and outer parts of the top element, which directs heat downwards onto the food. This function is suitable for grilling medium or large portions of sausages, bacon, steaks, fish etc. Ideally the thermostat control knob should be set to 200°C.

FAN AND GRILL: This method of cooking utilises the top element in conjunction with the fan, which helps to provide a quick circulation of heat. This function is suitable where quick browning is required and “sealing” the juices in, such as steaks, hamburgers, some vegetables etc.

FAN AND LOWER ELEMENT: This method of cooking utilises the bottom element in conjunction with the fan, which helps to circulate the heat. This function is suitable for sterilising and preserving jars.

Thermostat control knob (main oven)



The oven thermostat control knob should be turned clockwise and it sets the required temperature of the oven. It is possible to regulate the temperature within a range of 50 - 250°C.

Selecting an oven function and temperature (secondary oven)



If you turn the control knob clockwise, it will automatically select a conventional oven function and you can regulate the temperature between 50 - 250°C.

To use one of the other functions, you should turn the dial past the max. setting and select the following functions.

OVEN LIGHT: Separate light control which allows the light to be switched on, even when the oven is not heating.

UPPER ELEMENT ONLY: This method of cooking uses the outer part of the top element to direct gentle heat downwards onto the food. For gentle cooking, browning or keeping cooked dishes warm.

LOWER ELEMENT ONLY: This method of cooking uses the lower element to direct heat upwards to the food. For slow-cooking recipes or for warming up meals.

FULL GRILL: This method of cooking utilises the inner and outer parts of the top element, which directs heat downwards onto the food. This function is suitable for grilling medium or large portions of sausages, bacon, steaks, fish etc.

Oven operating light

This light will come on to indicate that the oven's heating elements are in operation. The light will turn off when the temperature set on the thermostat control knob has been reached. It will cycle on and off throughout the cooking time.

You should not place food inside the cavity, until the correct cooking temperature has been reached.

The cooling fan

- The cooling fan will operate as soon as the main oven function selector knob is turned to a cooking function (including the oven light function).

- If the main oven has been used at a high temperature and/or for a long period of time, you may wish the cooling fan to operate for a period of time after you have finished cooking.

- To achieve this, turn the main oven thermostat control knob to the off position. The main oven will stop heating, but the cooling fan will continue to run.

- When the main oven is sufficiently cool, you should turn the main oven function selector knob to the off position.

- **The cooling fan will not run if you are solely using the secondary oven.**

- If the secondary oven is going to be used at a high temperature or a long period of time, you may wish the cooling fan to operate during cooking and for a period of time after you have finished cooking.

- To achieve this, turn the main oven function selector knob to the oven light function. The main oven will not heat, but the cooling fan will fun.

- When you have finished cooking, you should turn the secondary oven control knob to the off position.

- When the main oven is sufficiently cool, you should turn the main oven function selector knob to the off position.

Fitting the grill deflector (secondary oven)





- **IMPORTANT: The grill deflector MUST be fitted when using the grill function in the secondary oven and the door left open.**

- Fit the grill deflector **(S)** into position and leave the door half way open.

- Turn the Oven function and thermostat control knob (secondary oven) to the symbol.

Using and assembling the rotisserie



- Place the food on the spit **(L)**, making sure that it is placed centrally between the two forks **(F)**. Otherwise excess strain will be placed on the motor **(R)**.

- Place one end of the spit **(L)** onto support **(G)** and put the opposite end into the hole of the motor **(P)**.

- Fill the drip tray with a little water and place this under the spit **(L)**.





- Fit the grill deflector **(S)** into position and leave the door half way open.

- Turn the Oven function and thermostat control knob (secondary oven) to the symbol.

- To rotate the spit in the opposite direction, whilst wearing a protective oven glove, turn the rotation knob **(A)**.

- Make sure that you press the Rotisserie On/Off button, then turn the Oven function and thermostat control knob (secondary oven) to 0 before attempting to remove the spit **(L)**.

Cooking guidelines

- Please refer to the information given on food packaging for guidance on cooking temperatures and times. Once familiar with the performance of your appliance, temperatures and times can be varied to suit personal preference.

- If you are using the fan oven function, then you should follow the information given on the food packaging for this particular mode of cooking.

- You should pre-heat the oven and not place food inside of it until the oven operating light has gone off. You can choose not to pre-heat when using the fan oven mode; however you should extend the cooking time given on the food packaging by at least ten minutes.

- **IMPORTANT:** You should pre-heat the oven if you are baking, regardless of whether you are using the conventional oven or fan oven functions.

- If there is no guidance given on the food packaging specifically for cooking in fan oven mode, you can generally reduce the cooking time and temperature by 10% from the information given for conventional oven cooking.

- Make sure that frozen foods are thoroughly thawed before cooking, unless the instructions on the food packaging advise that you can “cook from frozen”.

- Before cooking, check that any accessories that are not required are removed from the oven.

- Place cooking trays in the centre of the oven and leave gaps between the trays to allow air to circulate.

- Try to open the door as little as possible to view the dishes.

- The oven light will remain on during cooking.

Warnings

- Keep the oven door closed when using any of the grill or oven functions in the main oven.

- When using the grill function in the secondary oven, the heat deflector **MUST** be fitted and the door left open. For the remaining functions of the secondary oven, the oven door must be kept closed.

- Do not use aluminium foil to cover the enamelled baking tray or heat items wrapped in aluminium foil under the grill. The high reflectivity of the foil could potentially damage the grill element.

- You should also never line the base of your oven with aluminium foil.

- During cooking, never place pans or cookware directly onto the bottom of your oven. They should always be placed on the shelves provided.

- The grill heating element becomes extremely hot during operation, avoid touching it inadvertently when handling the food which you are grilling.

- **Important:** Be careful when opening the door, to avoid contact with hot parts and steam.

- When removing the enamelled baking tray, you should **ALWAYS** use an oven glove.

- **IMPORTANT:** In case of fire, close the main valve of the gas supply and switch off the electricity supply to the appliance. **NEVER** pour water onto burning oil.

Using the hob top

The following symbols will appear on the control panel, next to each control knob:

Black circle: gas off

 Large flame: maximum setting

Small flame: minimum setting

- The minimum setting is at the end of the anti-clockwise rotation of the control knob.
- All operation positions must be selected between the maximum and minimum positions.
- Never select a knob position between the maximum and off position.

Automatic electric ignition

To ignite a burner:

- Press in the control knob of the burner that you wish to light and turn it anti-clockwise to the maximum position.
- If you keep the control knob depressed, the automatic ignition for the burner will operate.
- As each burner has a flame failure safety device, once the burner has lit, you will need to keep the control knob pressed in for approximately 10 seconds.
- If after you let go of the control knob, the flame will go out and you should repeat the above process.
- In case of power failure, the burners can be lit by carefully using a match.
- If the burner flame goes out once it is lit, then the flame failure safety device will cut the supply of gas to the burner.

Energy saving tips

BURNERS	Pan size	
	Ø min.	Ø max
Auxiliary	120	140
Semi-rapid	160	200
Rapid	200	240
Wok	240	280

- The diameter of the bottom of the pan should correspond to that of the burner.



- The burner flame must never extend beyond the diametre of the pan.
- Use flat bottomed pans only
- When possible, keep a lid on the pan whilst cooking.
- Cook vegetables with as little water as possible, to reduce cooking times.

IMPORTANT: Always place pans centrally over the hob burners and position them so that the handles cannot get accidentally caught or knocked off. You should also make sure that the handle is not over one of the other hob burner flames.

Cleaning and maintenance

Cleaning operations must only be carried out when the oven is cool.

The appliance should be disconnected from your mains supply before commencing any cleaning process.

- The oven should be thoroughly cleaned before it is operated for the first time and after each use. This will avoid residual food stuffs becoming baked on the oven cavity. After residues have been baked on several times, they are far more difficult to remove.

- **Never** clean the oven surfaces by steam cleaning.

- The oven cavity should only be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.

- Any stains that may appear on the bottom of the oven will have originated from food splashes or spilt food, these splashes occur during the cooking process. These could possibly be a result of the food being cooked at an excessively high temperature or being placed in cookware that is too small.

- You should select a cooking temperature that is appropriate for the food that you are cooking. You should also ensure that the food is placed in an adequately sized dish and that you use the enamelled baking tray where appropriate.

- Outer parts of the oven should only be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.

- We would recommend that an appropriate stainless steel cleaner and polish is regularly used on the stainless steel surfaces of this appliance.

- If you use any form of oven cleaner on your appliance, then you must check with the manufacturer of the cleaner that it is suitable for use on your appliance.

- **Any damage that is caused to the appliance by a cleaning product will not be fixed by Baumatic free of charge, even if the appliance is within the guarantee period.**

Cleaning the hob burners

The hob burners should be cleaned once a week or more frequently if they get soiled.

- Remove the hob burners by pulling them upwards and away from the hob top.

- Soak them for about ten minutes in hot water and a little detergent.

- After cleaning and washing them, wipe and dry them carefully.

- Before placing the burners back on the hob top, **make sure that the gas jet is not blocked.**

- **IMPORTANT:** Make sure that you reassemble the burners in the original way.

Maintaining cast iron pan stands

- **IMPORTANT:** Make sure that the hob surface and pan stands have cooled before you attempt to touch them.

- Wipe the pan stands over with a soft, damp cloth that has been put into warm soapy water. The cloth should be wrung out after being taken out of the soapy water.

- Using a paper towel, thoroughly dry the pan stands.

- To maintain the appearance of the cast iron pan stands, we would recommend that you rub a small amount of olive oil into the pan stands. After you have finished cleaning them.

Replacing the oven bulb

IMPORTANT: The oven must be disconnected from your mains supply before you attempt to either remove or replace the oven bulb.



- Remove all oven shelves, the enamelled baking tray and the side rack that is on the same side as the oven light.

- Unscrew the lamp cover.

- Unscrew the bulb and remove it from its holder.

- Replace the bulb with a 25 W/300°C, screw type pigmy.

- **Do not** use any other type of bulb.

- Screw the lamp cover back into its original position.

Removing the oven door for cleaning



- Open the oven door fully.
- The hinges **(A)** are provided with two movable hooks **(B)**.
- Rotate the hooks into the slot **(C)**.
- You should grip the sides of the door at the centre and then incline it slightly towards the oven cavity and then by pulling it gently away from the oven cavity.
- **IMPORTANT:** You should make sure that the door is supported at all times and that you place the door on some padded material whilst cleaning it.
- The oven door and door glass should only be cleaned using a damp cloth and a small amount of detergent. The cloth **MUST NOT** have come into contact with any form of cleaning product or chemical previously.
- Replace the oven door by introducing the hinges back into their relevant slots. Before closing the doors **DO NOT FORGET TO RESET THE MOVABLE HOOKS.**
- **DO NOT** attempt to move the hooks whilst the door is not attached to the oven, as the hinges are under high spring tension and injury may result.

Installation

The installation must be carried out by a suitably qualified person, in accordance with the current version of the following.

- **UK Regulations and Safety Standards or their European Norm Replacements.**
- **Building Regulations** (issued by the Department of the Environment).
- **Building Standards** (issued by the Scottish Development Department).
- **IEE Wiring Regulations.**
- **Electricity At Work Regulations.**
- **Gas Safety (Installation and Use) (Amendment) Regulations.**

Positioning

The adjacent furniture and all materials used in the installation must be able to withstand a minimum temperature of 85°C above the ambient temperature of the room it is located in, whilst in use.

- Your appliance is heavy, so you should be careful when moving or positioning it.

- **Do not** try to move the cooker by pulling on either the door, handle or control panel.



- The cooker is designed to slot in between 600 mm deep cabinets, which are spaced approximately 940 mm apart.

- It can also be used as freestanding, with a cabinet to one side, in a corner setting or with its back to a wall.

- **IMPORTANT:** It should not be installed at the end of a run of cabinets, if there is a cabinet at immediate right angles to the cooker door.

- The wall behind the cooker and 450 mm above and across the width of the cooker should be an incombustible material and preferably an easy clean surface, such as ceramic tiles.

- Any overhanging surface or cooker hood should be **at least 700 mm** above the highest point on the hob top (including the burners).

- Baumatic do not recommend that the cooker is positioned below wall cupboards, as the heat and steam from the appliance and what is being cooked, may damage the cupboard and its contents.

- The cooker may be located in a kitchen, or a bedroom, but not in a room containing a bath or shower. **The cooker must not be installed in a bedroom of less than 20m³ in size.**

- **LPG models** must not be installed in a room or internal space below ground level (e.g. in a basement).



- The cooker is fitted with four legs that can be adjusted to match the height of your kitchen cabinets.

- To assemble them it is necessary to raise the cooker and to screw the four legs into position, on each corner of the base of the appliance.

- **IMPORTANT:** They must be screwed clockwise into position and not just slotted into the holes on each corner. You must screw them through the brackets that are also provided.

Gas connection

This appliance must be installed by a competent person in accordance with the current versions of the following UK (United Kingdom) or ROI (Republic of Ireland) Regulations and Safety Standards or their European Norm Replacements.

Important information

- This cooker is supplied to run on **natural gas only** and cannot be used on any other type of gas without modification.

- Conversion for use on LPG and other gases must only be undertaken by a qualified person. For information on the use of other gases, please contact the Baumatic Advice Line.

- The cooker must be installed by a qualified person, in accordance with the current edition of the Gas Safety (Installation and Use) (Amendment) Regulations and the relevant building/I.E.E. Regulations.

- Failure to install the appliance correctly could invalidate Baumatic's guarantee and lead to prosecution under the regulations quoted above.

- In the UK, **CORGI** registered installers are authorised to undertake the installation and service work, in compliance with the above regulations.

Ventilation requirements

- The room containing the cooker should have an air supply in accordance with the current edition of BS 5440: Part 2:

- The room must have opening windows or equivalent; some rooms may also require a permanent vent.

- If the room has a volume between 5 and 10m^3, it will require an air vent of 50cm^2 (effective area). Unless it has a door which opens directly to the outside.

- If the room has a volume of less than 5m^3, it will require an air vent of 100cm^2 (effective area).

- If there are any other fuel burning appliances in the same room the current edition of BS 5440: Part 2: should be consulted to determine air vent requirements.

- Ensure that the room containing the cooker is well ventilated, keep natural ventilation holes or install a mechanical ventilation device (mechanical cooker hood).

- Prolonged intensive use of the appliance may call for additional ventilation, either by the opening of a window, or by increasing the level of the mechanical ventilation device (where present).

- This cooker is not fitted with a device for discharging the products of combustion. Ensure that the ventilation rules and regulations are followed.

- Excess steam from the oven, vents out at the top back edge of the cooker, so make sure that the walls behind and near the cooker are resistant to heat, steam and condensation.

- Your cooker must stand on a flat surface so that when it is in position the hob is level. When in position check that the cooker is level by using a spirit level and adjust the 2 feet at the rear and the 2 feet at the front if necessary.

- Remember that the quantity of air necessary for combustion must never be less than $2m^3/h$ for each kW of power (see total power in kW on the appliance rating plate).

Gas Safety (Installation and Use) Regulations

- It is the law that all gas appliances are installed by competent persons in accordance with the current edition of the **Gas Safety Installation and Use Regulations**.

- It is in your interest and that of safety to ensure compliance with the law.

- In the UK, CORGI registered installers work to safe standards of practice. The cooker must also be installed in accordance with the current edition of BS 6172. Failure to install the cooker correctly could invalidate the warranty, liability claims and lead to prosecution.

- **IMPORTANT: It is a requirement for a stability chain to be fitted to the appliance. Please see page 33 for more detailed information on this.**

Gas connection

ALL INSTALLATION AND SERVICE WORK MUST BE CARRIED OUT BY A CORGI REGISTERED ENGINEER.

- Prior to installation, ensure that the gas supply conditions (nature of the gas and gas pressure) and the adjustment conditions are compatible. The adjustment conditions for this appliance are stated on the rating plate which can be found on the back cover.

- This appliance is not designed to be connected to a combustion product evacuation device. Particular attention should be given to the relevant requirements regarding ventilation.

- Connection to the cooker should be made with an approved appliance flexible connection to BS 669.

- If the cooker has been converted for use with LPG, then it should be connected to the gas supply using a bayonet type hose. The hose MUST be suitable for use with LPG gas. They are identifiable by a red band or stripe.

- A hose length of 0.9m to 1.25m is recommended. The length of hose chosen should be such that when the cooker is in situ, the hose does not touch the floor.

- Care should be taken to ensure that the temperature rise of areas at the rear of the cooker that are likely to come in contact with the flexible hose do not exceed 70°C.

- Gas pressure may be checked on a semi-rapid hob burner. Remove the appropriate injector and attach a test nipple. Light the other burners and observe that the gas pressure complies with the gas standards in force.



- This cooker can be connected to the supply both on the right and left hand side at the rear of the cooker. To reverse the position, remove the blanking plug and refit it to the opposite side to where the hose is being connected.

- **IMPORTANT: On completion carry out a gas tightness test.**

Gas adjustment (Conversion to LPG)

All work must be carried out by a CORGI registered engineer.

IMPORTANT: Always isolate the cooker from the electricity supply before changing the injectors and/or adjusting the minimum flow of the burners.



- Remove the pan-stands, burners and flame spreaders **(A)**.



- Unscrew the injector **(B)** and replace it with the stipulated injector for the new gas supply (see table below).

TECHNICAL DATA

BURNER TYPE (sizes mm)	GAS TYPE		PRESSURE (mbar)	INJECTOR MARKING (1/100 mm)	GAS CON-SUMPTION*	POWER (kW) MAX.	POWER (kW) MIN.
AUXILIARY Ø 55	liquid gas	G30/G31	28..30/37	52	73 g/h	**1.000**	**0.300**
	natural gas	G20	20	72 X	95 dm^3/h		
SEMIRAPID Ø 75	liquid gas	G30/G31	28..30/37	68	127 g/h	**1.750**	**0.440**
	natural gas	G20	20	98	167 dm^3/h		
RAPID Ø 100	liquid gas	G30/G31	28..30/37	88	218 g/h	**3.000**	**0.750**
	natural gas	G20	20	116	286 dm^3/h		
TRIPLE Ø 130	liquid gas	G30/G31	28..30/37	96	262 g/h	**3.600**	**1.500**
	natural gas	G20	20	135	343 dm^3/h		

- Reassemble all the burners carefully; in particular you should make sure that the flame spreader is correctly placed on the burner.

IMPORTANT: After changing the injectors YOU MUST follow the minimum flow adjustment section below.

Minimum flow adjustment for hob gas taps.

All work must be carried out by a CORGI registered engineer.



- Light the burner and set the knob at the minimum position.
- Remove the knob from the tap and place a small bladed screwdriver in the centre of the tap shaft.
- Unscrew the adjusting screw, in order to increase the gas flow or tighten the adjusting screw to decrease the gas flow.
- The correct adjustment is obtained when the flame has a length of about 3 – 4 mm.
- For butane/propane gas, the adjusting screw must be tightly screwed in.
- Refit the control knob.
- Make sure that the flame does not go out by quickly turning from maximum flow to minimum flow. If it does then remove the control knob and make further adjustments to the gas flow, testing it again once the adjustment has been made.
- **IMPORTANT: On completion carry out a gas tightness test.**

Fitting a stability chain

IMPORTANT: It is a legal requirement for your CORGI registered installer to fit a stability chain.


Stability hook
COOKER
Firmly fix the chain to the rear of the cooker
The stability chain should be as short as is practical

The stability hook should be securely fixed to the fabric of the building, in an adjacent position to the safety chain at the rear of the appliance.

The chain should be kept as short as is practical.

Electrical connection

This appliance must be installed by a qualified person in accordance with the latest edition of the I.E.E. Regulations and in compliance with Baumatic's instructions.

Before connecting the appliance, make sure that the supply voltage marked on the rating plate corresponds with your mains supply voltage.

WARNING: THIS APPLIANCE MUST BE EARTHED.

- This appliance must be wired into a 20 A double pole switched fused spur outlet, having 3 mm contact separation and placed in an easily accessible position adjacent to the appliance. It should not be located above the appliance and no more than 1.25m away from it.

- The spur outlet must still be accessible even when your oven is located in its operating position.

- Cable type: H05 RRF 3 core x 2.5 mm^3

Connecting the mains supply cable



IMPORTANT
The wires in the mains lead are coloured in accordance with the following code:

GREEN AND YELLOW	**EARTH**
BLUE	**NEUTRAL**
BROWN	**LIVE**

- Open the mains terminal block cover as shown, unscrew the cable clamp (A) and unscrew (not fully) the screws in the mains terminal block (L, N, E) which secure the three wires of the mains cable.

- Fit the cable and refit the cable clamp (A).

- Allow sufficient cable length for the cooker to be pulled out for cleaning, but do not let it hang closer than 50mm to the floor.

- The cable can be looped if necessary, but make sure that is not kinked or trapped when the cooker is in position.

Replacing the mains supply cable

If the mains supply cable is damaged, then it must be replaced by an appropriate replacement.

The mains supply cable should be replaced in accordance with the following instructions:

- **Switch the appliance off at the control switch.**
- Open the box of the supply board.
- Unscrew the clamp (A) fixing the cable.
- Replace the cable with one of the same length and in accordance with the specification given above.
- The “green-yellow” earth wire must be connected to the terminal marked ⏚. It must be about 10 mm longer than the live and neutral wires.
- The “blue” neutral wire must be connected to the terminal marked with letter (N) - the live wire must be connected to the terminal marked with letter (L).

My appliance isn't working correctly

- **The oven isn't coming on.**

* Check that the oven is in manual operation mode.

* Check that you have selected a cooking function and a cooking temperature.

- **There appears to be no power to the oven and grill.**

* Check that the appliance has been connected to the electrical mains supply correctly.

* Check that the mains fuses are in working order.

* Check that the operating instructions for setting the time of day and putting the appliance into manual operation mode have been followed.

- **The grill function works but the main oven does not.**

* Check that you have selected the correct cooking function.

- **The grill and top oven element is not working, or cuts out for long periods of time during use.**

* Allow the oven to cool for approximately 2 hours. Once cool, check whether the appliance is again working properly.

- **My food is not cooking properly**

* Ensure that you are selecting the correct temperature and the correct cooking function for the food that you are cooking. It may be appropriate to adjust your cooking temperature by plus or minus 10°C, to achieve the best cooking results.

- **My food is not cooking evenly**

* Check that the oven has been installed correctly and is level.

* Check that the correct temperatures and shelf positions are being used.

- **The oven light is not working**

* Refer to page 24 and follow the “Replacing the oven bulb” section.

- **I am getting condensation in my oven**

* Steam and condensation is a natural by product of cooking any food with high water content, such as frozen food, chicken etc.

* You may get condensation in the oven cavity and forming between the oven door glasses. This is not necessarily a sign that the oven is not working correctly.

* Do not leave food in the oven to cool after it has been cooked and the oven has been switched off.

* Use a covered container, where practical, when cooking to reduce the amount of condensation that forms.

IMPORTANT: If your appliance appears not to be operating correctly, then you should disconnect it from your mains supply and then contact Baumatic Customer Care on telephone number (0118) 933 6911.

DO NOT ATTEMPT TO REPAIR THE APPLIANCE YOURSELF.

Please note that if an engineer is asked to attend whilst the product is under guarantee and finds that the problem is not the result of an appliance fault, then you may be liable for the cost of the call out charge.

The appliance must be accessible for the engineer to perform any necessary repair. If your appliance is installed in such a way that an engineer is concerned that damage will be caused to the appliance or your kitchen, then he will not complete a repair.

This includes situations where appliances have been tiled in, sealed in with sealant, have wooden obstructions placed in front of the appliance, like plinths. Or any installation other than the one specified by Baumatic Ltd. has been completed.

Please refer to the conditions of guarantee that appear on the warranty card that you receive with the appliance.

United Kingdom
Baumatic Ltd.,
Baumatic Buildings,
6 Bennet Road,
Reading, Berkshire
RG2 0QX
United Kingdom

Sales Telephone
(0118) 933 6900
Sales Fax
(0118) 931 0035
Customer Care Telephone
(0118) 933 6911
Customer Care Fax
(0118) 986 9124
Spares Telephone
(01235) 437244
Advice Line Telephone
(0118) 933 6933

E-mail:
sales@baumatic.co.uk
customercare@baumatic.co.uk
spares@baumatic.co.uk
technical@baumatic.co.uk

Website:
www.baumatic.co.uk

Republic of Ireland
01- 6266 798

Czech Republic
Baumatic CR spol s.r.o.
Amperova 495
46215, Librec
Czech Republic

+420 800 185 263

www.baumatic.cz

Slovak Republic
Baumatic Slovakia, s.r.o.
Skultetyho 1
831 04 Bratislava 3
Slovakia

+421 255 640 618

Germany
Baumatic Gmbh
Janderstrasse 9
Mannheim, 68199
Germany

+4962 112 9190

www.baumatic.de

Italy
Baumatic Italia S.R.L.
Via Caltana 129
Campodarsego (Padova), 35011
Italy

+3904 9920 2297

www.baumatic.it

Holland
Baumatic Benelux B.V.
Grindzuigerstraat 22
1333 MS ALMERE
The Netherlands

+3136 549 1555

www.baumatic.nl

Baumatic

www.baumatic.com